

# USER'S MANUAL

Non-Harmful To Eyes!



## 01 PACKING LIST

- 1 Main body
- 2 AC Power cord
- 3 Instructions
- 4 Certificate

## 02 PARTS INSTRUCTION


- 1 Infrared induction
- 2 90s timing button
- 3 60s timing button
- 4 30s timing button
- 5 90s Low heat mode
- 6 AC power port

## 03 PRODUCT INSTRUCTION

- 1 Designed for professional nail experts.  
Could perfect cure UV gel/Builder/LED gel.

## 04 OPERATOIN INSTRUCTION

- 1 Connect the AC power line socket.
- 2 Press ON/OFF button 1-2s to open/close the machine. When the timing is counting, press button again to enter Standby mode to reset.



- 3 After the machine starting up, user can select times by 90s/60s/30s/90s (low heat mode) buttons. Enter into low heat mode, power enhances gradually over time, to resolve all pain problem caused by curing gels.
- 4 If user don't use the time setting buttons, Infrared sensor starts working when putting hands into the machine. Max working time lasts 120s.

## 05 TECHNICAL INSTRUCTION

- 1 24LEDs
- 2 Maximum power consumption: 48W
- 3 Rated input: 100-240V 50/60Hz 1A
- 4 Size: 150 185 80mm
- 5 Wave length: 365+405nm

## 06 CAUTIONS

- 1 Please read the instruction carefully before using the lamp.
- 2 Please use the correctly.
- 3 Not allow any liquid into the machine otherwise, damage may occur.
- 4 When timer button out of function, Please don't use.
- 5 Please AC power line, when leaving.
- 6 Please not to use the nail lamp when AC Power line.
- 7 Please not to turn on the machine excess than 600 minutes otherwise it may reduce the lifetime of nail lamp.
- 8 When using, please wear protective glasses and radiation protection suits.
- 9 The machine detects internal temperature automatically in longterm use, When the temperature is too high, the machine turns to low-power operation, Timing stops working and return tonormal power operation after lowering the temperature.

### Products Quality Warranty

- 1 thank you for choosing UVLED, in order to make you use this product safely and unworried, and to protect your interests better, our company will be in compliance with and implementation of basic-AQSIQ jointly Ministry of Information Industry, implementation after-sale service
- 2 Range does not belong service:
  - 1 beyond effective service or free maintenance period
  - 2 The damage or breakdown caused by customer inappropriated preservation, maintain or the usage that hasn't follow the manual.
  - 3 Consumer disassemble product
  - 4 The damaged caused by human factors (eg. misoperation, bump, improper voltage input)

Model: \_\_\_\_\_ Date of Purchase: \_\_\_\_\_

Dealer: \_\_\_\_\_ Name: \_\_\_\_\_

TEL: \_\_\_\_\_

Address: \_\_\_\_\_

- ▲ This document is the important evidence of the product after-sale service, please keep it properly!